








Buttons To Control Your DVR.

-  **Play**
-  **Pause**
-  **Stop**
-  **Fast Forward**
-  **Rewind**
-  **Record**
-  **LIVE** **Live TV**
-  **LIST** **List**
-  **Replay**







Controlling Live TV.

You now have the power to pause, rewind and get instant replays of the programs you are currently watching. With just a few buttons, you can control the broadcast just like a DVD.

- Press  to pause live TV.
- Press  or  to resume watching.
- Press  or  one, two or three times to go forward or back at different speeds.
- Press  to return to live TV.
- Press  button to see an instant replay.




Record while watching a show or record two shows at once.

Record two shows and watch another already recorded show at the same time.

- Tune to the channel you want to record.
- Press the  button on your remote control to begin recording. REC will appear on the digital display on the front of your DVR.
- Press the  button on the bottom of your remote.
- Find the Channel you wish to record using your Interactive Guide. You will now see a red light on the digital display on the front of your DVR with the channel number you tune to.
- Press the  button on your remote control to begin recording.
- To watch a previously recorded show at this time, press LIST and use the arrow buttons to highlight the show and hit .

Recording from the Interactive Guide.

Find shows airing up to 14 days from now. Watch them on your schedule.

- Press the  button to display the Interactive Guide.
- Use the arrow keys to highlight the program you want to record.
- Press the  button.
- If the program is starting or is currently airing, your box will tune to that channel and you will see REC on the digital display on the front of your DVR.
- To go to a different channel, hit the  button on the bottom of your remote and tune to the channel you wish to view.
- If the show is in the future, you may continue navigating to the program you wish to watch without the need to press the  button.


Watching what you recorded.

Watch what you recorded on your own schedule.

- Press the  button on your remote to view all the recorded programming you have stored in your DVR library.
- Use the arrow keys  to highlight the recording you want to watch.
- Press .
- Arrow to the right to highlight resume or restart from the beginning on the DVR menu.
- Press .
- Enjoy your program. Use your remote DVR buttons to pause, rewind or fast forward.

Erasing shows.

Make room for more programming on your DVR by erasing the shows stored in your library.

- Press the  button on your remote control to view saved shows.
- Use  to highlight the show you want to erase and press the .
- Arrow to the right to highlight the X on the DVR menu.
- Press .
- Press  again or if you've changed your mind, arrow down to Don't Delete Recording and hit .

“ The biggest advantage is it's so easy to record something. You go to the guide, you pick a show, you hit OK and it's done. Even my five-year-old is recording things! ”

“ We watch what we want to watch, when we want to watch it. That's the biggest thing for me. You're no longer a slave to a time slot. You can even set it once and record the whole season of your favorite show! ”